


APPROACHING OR LEAVING A HELICOPTER




Do not approach without receiving a visual signal from the pilot. Do not leave without a visual or spoken instruction to do so. Stay where the pilot can see you at all times.




On sloping ground always approach or leave on the downslope side for maximum rotor clearance.



If blinded by swirling dust or grit, STOP – crouch lower, or sit down and wait for assistance.



If disembarking while the helicopter is hovering, get out slowly and smoothly when cleared to by the pilot.



Do not approach or leave a helicopter when the engine and rotors are running down or starting up.



Crouch while walking for extra rotor clearance. Always remove hats. Never reach up or chase after anything that blows away.



Carry long objects horizontally below waist level – never upright or on the shoulder.

TAKEOFF, LANDING AND LOADING OPERATIONS




Clear helipad of loose articles. Secure your gear from the effect of rotor wash.




When transporting personnel, loading staff should ensure that:


- Passengers are briefed on approaching and leaving the helicopter.
- They are grouped together and positioned to one side of the landing zone.
- They face away from the helicopter during takeoff and landing.
- Each person looks after their own gear.
- They are ready to board in turn as soon as the pilot give the signal, and they are escorted to the helicopter.



When directing the pilot for landing, stand with back to the wind and arms raised.



When directing the pilot by radio, remember they may be too busy to give a reply.






Fasten and adjust your seat belt on entering the helicopter and leave it fastened until the pilot signals you to get out.






Al-Burhan Airways

الاقتراب او مغادرة طائرة الهليكوبتر

مناطق السلامة للهليكوبتر



الانطلاق، الهبوط، عمليات التحميل



- تقديم ملخص بالمعلومات للمسافرين عن كيفية الاقتراب ومغادرة طائرة الهليكوبتر.
- يتم وضع المسافرين سوية وفي الجانب الذي سيتم منه النزول عند الهبوط.
- ابعاد وجوه المسافرين عن منظر واجهة الهليكوبتر اثناء الاقلاع والهبوط.
- ان يحافظ كل مسافر على الاتزان واجراءات السلامة الخاصة به.
- ان يستعد المسافرين للصعود الى الطائرة تباعا وحالما يعطيهم الطيار الاشارة ويتم مرافقتهم اثناء الصعود للطائرة.



Al-Burhan Airways